



280 LITRE
THE SLIMLINE
 GARDEN PLANTER
 INSTALLATION GUIDE



Ecosure
 Efills Ltd
 Unit 1
 Whiting Way
 Melbourn
 Hertfordshire
 SG8 6NA

Phone: 01763 261781
 Fax: 01763 268409
 Email: sales@ecosure.co.uk
 Website: www.ecosure.co.uk





SLIMLINE WATER BUTT INSTALLATION GUIDE

RAINWATER DIVERTERS MUST BE INSTALLED BELOW THE BOTTOM OF THE BOWL OF THE PLANTER.

a. Position the water butt a maximum of 500mm from the rainwater down-pipe.



b. Using a 32mm hole-saw or spade bit, cut a hole just below the base of the planter bowl and insert the rubber seal.



c. Fit the rainwater diverter to the downpipe according to the manufacturer's installation instructions.



d. Trim the connecting pipe if required, and push one end on to the diverter. Push the other end through the seal fitted onto the tank. Lubricate if necessary.



e. If, when fixing a tap to the raised outlet, the tap does not face downwards, use another layer of PTFE and try again. Do not use too much tape as this may damage the threaded outlet. Hand tighten only; do not use a spanner or wrench.



THANK YOU

Thank you for buying the 280 Litre Slimline Water Butt Planter. We hope you will be completely satisfied with your purchase. This industrial strength product is guaranteed frost-proof and is made from UV stabilised polymer.

IMPORTANT SAFETY INSTRUCTIONS

The Ecosure Slimline Water Butt Planter must be sited on a flat, level base.

- When fixing your tap or valve to the moulded outlets, use 4 or 5 layers of PTFE tape and **DO NOT OVERTIGHTEN**. Hand tighten only; do not use a spanner or wrench.
- When using any power tools, be aware of others around you and wear suitable PPE (e.g. eye protectors and gloves).