





ECOSURE IBC BUND POSITIONING GUIDELINES



Ensure the outlet of your IBC faces forwards



Your IBC pallet should be centrally located on the IBC bund support columns.